

TIERS	DESCRIPTION	CAPACITY/ROW	TOTAL CAPACITY
2-TIER			
	PERMANENT MOUNT - 2 TIER - 7'6" - ALUM - SINGLE STEP	5	10
	PERMANENT MOUNT - 2 TIER - 12' - ALUM - SINGLE STEP	8	16
	PERMANENT MOUNT - 2 TIER - 15' - ALUM - SINGLE STEP	10	20
	PERMANENT MOUNT - 2 TIER - 21' - ALUM - SINGLE STEP	14	28
	PERMANENT MOUNT - 2 TIER - 7'6" - ALUM - DOUBLE STEP	5	10
	PERMANENT MOUNT - 2 TIER - 12' - ALUM - DOUBLE STEP	8	16
	PERMANENT MOUNT - 2 TIER - 15' - ALUM - DOUBLE STEP	10	20
	PERMANENT MOUNT - 2 TIER - 21' - ALUM - DOUBLE STEP	14	28
3-TIER			
	PERMANENT MOUNT - 3 TIER - 7'6" - ALUM - SINGLE STEP	5	15
	PERMANENT MOUNT - 3 TIER - 12' - ALUM - SINGLE STEP	8	24
	PERMANENT MOUNT - 3 TIER - 15' - ALUM - SINGLE STEP	10	30
	PERMANENT MOUNT - 3 TIER - 21' - ALUM - SINGLE STEP	14	42
	PERMANENT MOUNT - 3 TIER - 7'6" - ALUM - DOUBLE STEP	5	15
	PERMANENT MOUNT - 3 TIER - 12' - ALUM - DOUBLE STEP	8	24
	PERMANENT MOUNT - 3 TIER - 15' - ALUM - DOUBLE STEP	10	30
	PERMANENT MOUNT - 3 TIER - 21' - ALUM - DOUBLE STEP	14	42
4-TIER			
	PERMANENT MOUNT - 4 TIER - 7'6" - ALUM - DOUBLE STEP	5	20
	PERMANENT MOUNT - 4 TIER - 12' - ALUM - DOUBLE STEP	8	32
	PERMANENT MOUNT - 4 TIER - 15' - ALUM - DOUBLE STEP	10	40
	PERMANENT MOUNT - 4 TIER - 21' - ALUM - DOUBLE STEP	14	56
5-TIER			
	PERMANENT MOUNT - 5 TIER - 7'6" - ALUM - DOUBLE STEP	5	25
	PERMANENT MOUNT - 5 TIER - 12' - ALUM - DOUBLE STEP	8	40
	PERMANENT MOUNT - 5 TIER - 15' - ALUM - DOUBLE STEP	10	50
	PERMANENT MOUNT - 5 TIER - 21' - ALUM - DOUBLE STEP	14	70

SEATING FORMULA = LENGTH OF BLEACHER IN INCHES / 18 * NUMBER OF TIERS